

Vantage Series 4000 Strap On Sensor Installation- Zee Shot <14 inch


The following is an instruction on installing the strap on sensor for the Vantage Series 4000. There are two styles of strap on sensors. One is referred to as Small Strap On sensor (used on pipe sizes 1”-8”) the other is the Large Strap On sensor (used on pipe sizes 4”-120”). The Zee Shot sensor rails will accommodate both the Small and Large sensors so the mounting configurations will be the same for either sensor. It is important to note, however, that the electronics unit will need to be programmed for the specific sensor used.

Where do I place my sensors in relation to upstream and downstream conditions?

The ultrasonic transit time flow meter accuracies are based upon well developed velocity profiles. Upstream disturbances such as pumps or tees and elbows will effect the velocity profile. Below is a recommended straight runs to assure meter accuracies.

Device	Upstream from meter(in pipe diameters)	Downstream from meter(in pipe diameters)
Tees & Elbows	10-15	2-3
Reducers	10	2-3
Increases	20	2-3
Valves (fully opened)	10-15	2-3
Valves (modulating)	20-25	2-3
Pumps	20-25	2-3

In vertical runs, the flow should always be flowing up and never down.



The sensor/sensor holders should always be placed on the side of the pipe as Shown on the left and never on the top or the bottom of the pipe.

Note:
Cast or Ductile Pipe

Sand pipe to a smooth surface under sensor face

1

Note:
Asbestos Cement Pipe

Place coat of shellac on pipe surface under sensor face

2

Stand Here to install Sensor & speedrail #1

X

3
(Top View)

Place Long Speedrail #1 On Pipe

4


Attach chains to hook

5


Rotate Speedrail to center of pipe

6


Use level on side of Speedrail to locate center pipe position




Finger tighten chains with wingnuts




Place bead of silicone grease on face of each sensor




Place edge of Sensor #1 at Zero on Ruler




Slide clamp over center of Sensor




Secure sensor with thumbscrew (fingertight only)




SPEEDRAIL #2




Let Chains Over Lap Sensor Rail #1



Rotate Speedrail #2 to center of pipe (opposite of rail #1)




Use level on side of Speedrail to locate center pipe position




Finger tighten chains with wingnuts




Place bead of silicone grease on face of each sensor




Sensor Separation




Slide clamp over center of Sensor



Secure sensor with thumbscrew (fingertight only)





Refer to IOM manual for wiring of sensor cables to electronics.